

Contrex M-Series Driver

© 2018 PTC Inc. All Rights Reserved.

Table of Contents

Contrex M-Series Driver	1
Table of Contents	2
Contrex M-Series Driver	4
Overview	4
Setup	5
Channel Properties — General	6
Channel Properties — Serial Communications	7
Channel Properties — Write Optimizations	9
Channel Properties — Advanced	10
Device Properties — General	11
Device Properties — Scan Mode	12
Device Properties — Timing	13
Device Properties — Auto-Demotion	14
Device Properties — Device Settings	15
Device Properties — Redundancy	15
Data Types Description	16
Address Descriptions	17
M-Cut Addressing	17
M-Drive Addressing	18
M-Rotary Addressing	19
M-Shuttle Addressing	19
M-Track Addressing	20
M-Traverse Addressing	21
M-Trim Addressing	22
ML-Drive Addressing	23
ML-Trim Addressing	23
Error Descriptions	25
Missing address	25
Device address '<address>' contains a syntax error	25
Address '<address>' is out of range for the specified device or register	26
Device address '<address>' is not supported by model '<model name>'	26
Data Type '<type>' is not valid for device address '<address>'	26
Device address '<address>' is Read Only	26
COMn does not exist	27
Error opening COMn	27

COMn is in use by another application	27
Unable to set comm parameters on COMn	27
Communications error on '<channel name>' [<error mask>]	27
Device '<device name>' is not responding	28
Unable to write to '<address>' on device '<device name>.' Contrex Error (<error code>) <error description>	28
Deactivating Tag '<address>' on device '<device name>.' Contrex Error (<error code>) <error description>	29
Resources	30
Index	31

Contrex M-Series Driver

Help version 1.015

CONTENTS

[Overview](#)

What is the Contrex M-Series Driver?

[Device Setup](#)

How do I configure a device for use with this driver?

[Data Types Description](#)

What data types does this driver support?

[Address Descriptions](#)

How do I address a data location on a Contrex M-Series device?

[Error Descriptions](#)

What error messages does the Contrex M-Series Driver produce?

Overview

The Contrex M-Series Driver provides a reliable way to connect Contrex M-Series devices to OPC Client applications; including HMI, SCADA, Historian, MES, ERP, and countless custom applications.

Setup

Supported Devices

M-Cut
M-Drive
M-Rotary
M-Shuttle
M-Track
M-Traverse
M-Trim
ML-Drive
ML-Trim

Communication Protocol

M-Series Data-Link Protocol (4 byte/ 8 byte).

M-Drive, M-Trim, ML-Drive and ML-Trim utilize the 4 byte protocol.

M-Cut, M-Rotary, M-Shuttle, M-Track, and M-Traverse utilize the 8 byte protocol.

Supported Communication Parameters*

Baud Rate: 300, 600, 1200, 2400, 9600**

Parity: None, Even

Data Bits: 7, 8

Stop Bits: 1, 2

*Not all devices support the listed configurations. Consult the device documentation and configuration for more details.

**This is the default setting.

Ethernet Encapsulation

This driver supports Ethernet Encapsulation. Ethernet Encapsulation allows the driver to communicate with serial devices attached to an Ethernet network using a terminal server. Ethernet Encapsulation mode is invoked by selecting it the Physical Medium property located in the Serial Communications property group under Channel Properties. For more information, refer to the main OPC Server help file.

Device IDs

Valid Device IDs range from 0 to 32.

Device ID 0 is used to identify broadcast messages. A device topic can be configured within a server that uses a Device ID of station 0. All tags and data associated with this broadcast topic will be treated as Write Only. By defining a broadcast topic in the Server project, an M-Series command may be issued to multiple controllers simultaneously.

● **Note:** Selecting a broadcast device with a 4 byte model (M-Drive, M-Trim, ML-Drive or ML-Trim) will utilize the 4 byte protocol. Therefore, 8 byte devices (M-Cut, M-Rotary, M-Shuttle, M-Track, and M-Traverse) coexisting on the same channel will not process these messages. The reverse is true if the broadcast device is set to use an 8 byte model.

Flow Control

When using an RS232/485 converter, the type of flow control that is required will depend upon the needs of the converter. Some converters do not require any flow control and others will require RTS flow. Consult the converter's documentation to determine its flow requirements.

• See Also: [Settings](#).

Channel Properties — General

This server supports the use of simultaneous multiple communications drivers. Each protocol or driver used in a server project is called a channel. A server project may consist of many channels with the same communications driver or with unique communications drivers. A channel acts as the basic building block of an OPC link. This group is used to specify general channel properties, such as the identification attributes and operating mode.

Property Groups General Write Optimizations Advanced	<table border="1"> <tr> <td colspan="2">[-] Identification</td> </tr> <tr> <td>Name</td> <td></td> </tr> <tr> <td>Description</td> <td></td> </tr> <tr> <td>Driver</td> <td></td> </tr> <tr> <td colspan="2">[-] Diagnostics</td> </tr> <tr> <td>Diagnostics Capture</td> <td>Disable</td> </tr> </table>	[-] Identification		Name		Description		Driver		[-] Diagnostics		Diagnostics Capture	Disable
[-] Identification													
Name													
Description													
Driver													
[-] Diagnostics													
Diagnostics Capture	Disable												

Identification

Name: User-defined identity of this channel. In each server project, each channel name must be unique. Although names can be up to 256 characters, some client applications have a limited display window when browsing the OPC server's tag space. The channel name is part of the OPC browser information.

• For information on reserved characters, refer to "How To... Properly Name a Channel, Device, Tag, and Tag Group" in the server help.

Description: User-defined information about this channel.

• Many of these properties, including Description, have an associated system tag.

Driver: Selected protocol / driver for this channel. This property specifies the device driver that was selected during channel creation. It is a disabled setting in the channel properties.

• **Note:** With the server's online full-time operation, these properties can be changed at any time. This includes changing the channel name to prevent clients from registering data with the server. If a client has already acquired an item from the server before the channel name is changed, the items are unaffected. If, after the channel name has been changed, the client application releases the item and attempts to re-acquire using the old channel name, the item is not accepted. With this in mind, changes to the properties should not be made once a large client application has been developed. Utilize the User Manager to prevent operators from changing properties and restrict access rights to server features.

Diagnostics

Diagnostics Capture: When enabled, this option makes the channel's diagnostic information available to OPC applications. Because the server's diagnostic features require a minimal amount of overhead processing, it is recommended that they be utilized when needed and disabled when not. The default is disabled.

• **Note:** This property is disabled if the driver does not support diagnostics.

• For more information, refer to "Communication Diagnostics" in the server help.

Channel Properties — Serial Communications

Serial communication properties are available to serial drivers and vary depending on the driver, connection type, and options selected. Below is a superset of the possible properties.

Click to jump to one of the sections: [Connection Type](#), [Serial Port Settings](#) or [Ethernet Settings](#), and [Operational Behavior](#).

Note: With the server's online full-time operation, these properties can be changed at any time. Utilize the User Manager to restrict access rights to server features, as changes made to these properties can temporarily disrupt communications.

<p>Property Groups</p> <ul style="list-style-type: none"> General <li style="background-color: #e6f2ff;">Serial Communications Write Optimizations Advanced Communication Serialization 	<p><input type="checkbox"/> Connection Type</p> <table border="1"> <tr> <td>Physical Medium</td> <td>COM Port</td> </tr> <tr> <td>Shared</td> <td>No</td> </tr> </table> <p><input type="checkbox"/> Serial Port Settings</p> <table border="1"> <tr> <td>COM ID</td> <td>6</td> </tr> <tr> <td>Baud Rate</td> <td>9600</td> </tr> <tr> <td>Data Bits</td> <td>8</td> </tr> <tr> <td>Parity</td> <td>Even</td> </tr> <tr> <td>Stop Bits</td> <td>1</td> </tr> <tr> <td>Flow Control</td> <td>None</td> </tr> </table> <p><input type="checkbox"/> Operational Behavior</p> <table border="1"> <tr> <td>Report Comm. Errors</td> <td>Enable</td> </tr> <tr> <td>Close Idle Connection</td> <td>Enable</td> </tr> <tr> <td>Idle Time to Close (s)</td> <td>15</td> </tr> </table>	Physical Medium	COM Port	Shared	No	COM ID	6	Baud Rate	9600	Data Bits	8	Parity	Even	Stop Bits	1	Flow Control	None	Report Comm. Errors	Enable	Close Idle Connection	Enable	Idle Time to Close (s)	15
Physical Medium	COM Port																						
Shared	No																						
COM ID	6																						
Baud Rate	9600																						
Data Bits	8																						
Parity	Even																						
Stop Bits	1																						
Flow Control	None																						
Report Comm. Errors	Enable																						
Close Idle Connection	Enable																						
Idle Time to Close (s)	15																						

Connection Type

Physical Medium: Choose the type of hardware device for data communications. Options include COM Port, None, Modem, and Ethernet Encapsulation. The default is COM Port.

- **None:** Select None to indicate there is no physical connection, which displays the [Operation with no Communications](#) section.
- **COM Port:** Select Com Port to display and configure the [Serial Port Settings](#) section.
- **Modem:** Select Modem if phone lines are used for communications, which are configured in the [Modem Settings](#) section.
- **Ethernet Encap.:** Select if Ethernet Encapsulation is used for communications, which displays the [Ethernet Settings](#) section.
- **Shared:** Verify the connection is correctly identified as sharing the current configuration with another channel. This is a read-only property.

Serial Port Settings

COM ID: Specify the Communications ID to be used when communicating with devices assigned to the channel. The valid range is 1 to 9991 to 16. The default is 1.

Baud Rate: Specify the baud rate to be used to configure the selected communications port.

Data Bits: Specify the number of data bits per data word. Options include 5, 6, 7, or 8.

Parity: Specify the type of parity for the data. Options include Odd, Even, or None.


Stop Bits: Specify the number of stop bits per data word. Options include 1 or 2.

Flow Control: Select how the RTS and DTR control lines are utilized. Flow control is required to communicate with some serial devices. Options are:

- **None:** This option does not toggle or assert control lines.
- **DTR:** This option asserts the DTR line when the communications port is opened and remains on.
- **RTS:** This option specifies that the RTS line is high if bytes are available for transmission. After all buffered bytes have been sent, the RTS line is low. This is normally used with RS232/RS485 converter hardware.
- **RTS, DTR:** This option is a combination of DTR and RTS.
- **RTS Always:** This option asserts the RTS line when the communication port is opened and remains on.
- **RTS Manual:** This option asserts the RTS line based on the timing properties entered for RTS Line Control. It is only available when the driver supports manual RTS line control (or when the properties are shared and at least one of the channels belongs to a driver that provides this support).

RTS Manual adds an **RTS Line Control** property with options as follows:


- **Raise:** This property specifies the amount of time that the RTS line is raised prior to data transmission. The valid range is 0 to 9999 milliseconds. The default is 10 milliseconds.
- **Drop:** This property specifies the amount of time that the RTS line remains high after data transmission. The valid range is 0 to 9999 milliseconds. The default is 10 milliseconds.
- **Poll Delay:** This property specifies the amount of time that polling for communications is delayed. The valid range is 0 to 9999. The default is 10 milliseconds.

 **Tip:** When using two-wire RS-485, "echoes" may occur on the communication lines. Since this communication does not support echo suppression, it is recommended that echoes be disabled or a RS-485 converter be used.

Operational Behavior

- **Report Comm. Errors:** Enable or disable reporting of low-level communications errors. When enabled, low-level errors are posted to the Event Log as they occur. When disabled, these same errors are not posted even though normal request failures are. The default is Enable.
- **Close Idle Connection:** Choose to close the connection when there are no longer any tags being referenced by a client on the channel. The default is Enable.
- **Idle Time to Close:** Specify the amount of time that the server waits once all tags have been removed before closing the COM port. The default is 15 seconds.

Ethernet Settings

 **Note:** Not all serial drivers support Ethernet Encapsulation. If this group does not appear, the functionality is not supported.

Ethernet Encapsulation provides communication with serial devices connected to terminal servers on the Ethernet network. A terminal server is essentially a virtual serial port that converts TCP/IP messages on the Ethernet network to serial data. Once the message has been converted, users can connect standard devices that support serial communications to the terminal server. The terminal server's serial port must be properly configured to match the requirements of the serial device to which it is attached. *For more information, refer to "How To... Use Ethernet Encapsulation" in the server help.*

- **Network Adapter:** Indicate a network adapter to bind for Ethernet devices in this channel. Choose a network adapter to bind to or allow the OS to select the default.
 • *Specific drivers may display additional Ethernet Encapsulation properties. For more information, refer to Channel Properties - Ethernet Encapsulation.*

Modem Settings

- **Modem:** Specify the installed modem to be used for communications.
- **Connect Timeout:** Specify the amount of time to wait for connections to be established before failing a read or write. The default is 60 seconds.
- **Modem Properties:** Configure the modem hardware. When clicked, it opens vendor-specific modem properties.
- **Auto-Dial:** Enables the automatic dialing of entries in the Phonebook. The default is Disable. *For more information, refer to "Modem Auto-Dial" in the server help.*
- **Report Comm. Errors:** Enable or disable reporting of low-level communications errors. When enabled, low-level errors are posted to the Event Log as they occur. When disabled, these same errors are not posted even though normal request failures are. The default is Enable.
- **Close Idle Connection:** Choose to close the modem connection when there are no longer any tags being referenced by a client on the channel. The default is Enable.
- **Idle Time to Close:** Specify the amount of time that the server waits once all tags have been removed before closing the modem connection. The default is 15 seconds.

Operation with no Communications

- **Read Processing:** Select the action to be taken when an explicit device read is requested. Options include Ignore and Fail. Ignore does nothing; Fail provides the client with an update that indicates failure. The default setting is Ignore.

Channel Properties — Write Optimizations

As with any OPC server, writing data to the device may be the application's most important aspect. The server intends to ensure that the data written from the client application gets to the device on time. Given this goal, the server provides optimization properties that can be used to meet specific needs or improve application responsiveness.

Property Groups	<input type="checkbox"/> Write Optimizations	
General	Optimization Method	Write Only Latest Value for All Tags
Write Optimizations	Duty Cycle	10

Write Optimizations

Optimization Method: controls how write data is passed to the underlying communications driver. The options are:

- **Write All Values for All Tags:** This option forces the server to attempt to write every value to the controller. In this mode, the server continues to gather write requests and add them to the server's internal write queue. The server processes the write queue and attempts to empty it by writing data

to the device as quickly as possible. This mode ensures that everything written from the client applications is sent to the target device. This mode should be selected if the write operation order or the write item's content must uniquely be seen at the target device.

- **Write Only Latest Value for Non-Boolean Tags:** Many consecutive writes to the same value can accumulate in the write queue due to the time required to actually send the data to the device. If the server updates a write value that has already been placed in the write queue, far fewer writes are needed to reach the same final output value. In this way, no extra writes accumulate in the server's queue. When the user stops moving the slide switch, the value in the device is at the correct value at virtually the same time. As the mode states, any value that is not a Boolean value is updated in the server's internal write queue and sent to the device at the next possible opportunity. This can greatly improve the application performance.

● **Note:** This option does not attempt to optimize writes to Boolean values. It allows users to optimize the operation of HMI data without causing problems with Boolean operations, such as a momentary push button.

- **Write Only Latest Value for All Tags:** This option takes the theory behind the second optimization mode and applies it to all tags. It is especially useful if the application only needs to send the latest value to the device. This mode optimizes all writes by updating the tags currently in the write queue before they are sent. This is the default mode.

Duty Cycle: is used to control the ratio of write to read operations. The ratio is always based on one read for every one to ten writes. The duty cycle is set to ten by default, meaning that ten writes occur for each read operation. Although the application is performing a large number of continuous writes, it must be ensured that read data is still given time to process. A setting of one results in one read operation for every write operation. If there are no write operations to perform, reads are processed continuously. This allows optimization for applications with continuous writes versus a more balanced back and forth data flow.

● **Note:** It is recommended that the application be characterized for compatibility with the write optimization enhancements before being used in a production environment.

Channel Properties — Advanced

This group is used to specify advanced channel properties. Not all drivers support all properties; so the Advanced group does not appear for those devices.

Property Groups	[-] Non-Normalized Float Handling	
General	Floating-Point Values	Replace with Zero
Write Optimizations	[-] Inter-Device Delay	
Advanced	Inter-Device Delay (ms)	0

Non-Normalized Float Handling: A non-normalized value is defined as Infinity, Not-a-Number (NaN), or as a Denormalized Number. The default is Replace with Zero. Drivers that have native float handling may default to Unmodified. Non-normalized float handling allows users to specify how a driver handles non-normalized IEEE-754 floating point data. Descriptions of the options are as follows:

- **Replace with Zero:** This option allows a driver to replace non-normalized IEEE-754 floating point values with zero before being transferred to clients.
- **Unmodified:** This option allows a driver to transfer IEEE-754 denormalized, normalized, non-number, and infinity values to clients without any conversion or changes.

● **Note:** This property is disabled if the driver does not support floating point values or if it only supports the option that is displayed. According to the channel's float normalization setting, only real-time driver tags

(such as values and arrays) are subject to float normalization. For example, EFM data is not affected by this setting.

• For more information on the floating point values, refer to "How To ... Work with Non-Normalized Floating Point Values" in the server help.

Inter-Device Delay: Specify the amount of time the communications channel waits to send new requests to the next device after data is received from the current device on the same channel. Zero (0) disables the delay.

• **Note:** This property is not available for all drivers, models, and dependent settings.

Device Properties — General

A device represents a single target on a communications channel. If the driver supports multiple controllers, users must enter a device ID for each controller.

Property Groups		
General	[-] Identification	
Scan Mode	Name	
	Description	
	Channel Assignment	
	Driver	
	Model	
	ID Format	Decimal
	ID	2
	[-] Operating Mode	
	Data Collection	Enable
	Simulated	No

Identification

Name: This property specifies the name of the device. It is a logical user-defined name that can be up to 256 characters long, and may be used on multiple channels.

• **Note:** Although descriptive names are generally a good idea, some OPC client applications may have a limited display window when browsing the OPC server's tag space. The device name and channel name become part of the browse tree information as well. Within an OPC client, the combination of channel name and device name would appear as "ChannelName.DeviceName".

• For more information, refer to "How To... Properly Name a Channel, Device, Tag, and Tag Group" in server help.

Description: User-defined information about this device.

• Many of these properties, including Description, have an associated system tag.

Channel Assignment: User-defined name of the channel to which this device currently belongs.

Driver: Selected protocol driver for this device. This property specifies the driver selected during channel creation. It is disabled in the channel properties.

Model: This property specifies the specific type of device that is associated with this ID. The contents of the drop-down menu depends on the type of communications driver being used. Models that are not supported by a driver are disabled. If the communications driver supports multiple device models, the model selection can only be changed when there are no client applications connected to the device.

● **Note:** If the communication driver supports multiple models, users should try to match the model selection to the physical device. If the device is not represented in the drop-down menu, select a model that conforms closest to the target device. Some drivers support a model selection called "Open," which allows users to communicate without knowing the specific details of the target device. For more information, refer to the driver help documentation.

ID: This property specifies the device's station / node / identity / address. The type of ID entered depends on the communications driver being used. For many drivers, the ID is a numeric value. Drivers that support a Numeric ID provide users with the option to enter a numeric value whose format can be changed to suit the needs of the application or the characteristics of the selected communications driver. The ID format can be Decimal, Octal, and Hexadecimal. If the driver is Ethernet-based or supports an unconventional station or node name, the device's TCP/IP address may be used as the device ID. TCP/IP addresses consist of four values that are separated by periods, with each value in the range of 0 to 255. Some device IDs are string based. There may be additional properties to configure within the ID field, depending on the driver.

Operating Mode

Data Collection: This property controls the device's active state. Although device communications are enabled by default, this property can be used to disable a physical device. Communications are not attempted when a device is disabled. From a client standpoint, the data is marked as invalid and write operations are not accepted. This property can be changed at any time through this property or the device system tags.

Simulated: This option places the device into Simulation Mode. In this mode, the driver does not attempt to communicate with the physical device, but the server continues to return valid OPC data. Simulated stops physical communications with the device, but allows OPC data to be returned to the OPC client as valid data. While in Simulation Mode, the server treats all device data as reflective: whatever is written to the simulated device is read back and each OPC item is treated individually. The item's memory map is based on the group Update Rate. The data is not saved if the server removes the item (such as when the server is reinitialized). The default is No.

● **Notes:**

1. This System tag (_Simulated) is read only and cannot be written to for runtime protection. The System tag allows this property to be monitored from the client.
2. In Simulation mode, the item's memory map is based on client update rate(s) (Group Update Rate for OPC clients or Scan Rate for native and DDE interfaces). This means that two clients that reference the same item with different update rates return different data.

● Simulation Mode is for test and simulation purposes only. It should never be used in a production environment.

Device Properties — Scan Mode

The Scan Mode specifies the subscribed-client requested scan rate for tags that require device communications. Synchronous and asynchronous device reads and writes are processed as soon as possible; unaffected by the Scan Mode properties.

Property Groups	☐ Scan Mode	
General	Scan Mode	Respect Client-Specified Scan Rate ▼
Scan Mode	Initial Updates from Cache	Disable

Scan Mode: specifies how tags in the device are scanned for updates sent to subscribed clients.

Descriptions of the options are:

- **Respect Client-Specified Scan Rate:** This mode uses the scan rate requested by the client.
- **Request Data No Faster than Scan Rate:** This mode specifies the maximum scan rate to be used. The valid range is 10 to 99999990 milliseconds. The default is 1000 milliseconds.
 - **Note:** When the server has an active client and items for the device and the scan rate value is increased, the changes take effect immediately. When the scan rate value is decreased, the changes do not take effect until all client applications have been disconnected.
- **Request All Data at Scan Rate:** This mode forces tags to be scanned at the specified rate for subscribed clients. The valid range is 10 to 99999990 milliseconds. The default is 1000 milliseconds.
- **Do Not Scan, Demand Poll Only:** This mode does not periodically poll tags that belong to the device nor perform a read to get an item's initial value once it becomes active. It is the client's responsibility to poll for updates, either by writing to the `_DemandPoll` tag or by issuing explicit device reads for individual items. *For more information, refer to "Device Demand Poll" in server help.*
- **Respect Tag-Specified Scan Rate:** This mode forces static tags to be scanned at the rate specified in their static configuration tag properties. Dynamic tags are scanned at the client-specified scan rate.

Initial Updates from Cache: When enabled, this option allows the server to provide the first updates for newly activated tag references from stored (cached) data. Cache updates can only be provided when the new item reference shares the same address, scan rate, data type, client access, and scaling properties. A device read is used for the initial update for the first client reference only. The default is disabled; any time a client activates a tag reference the server attempts to read the initial value from the device.

Device Properties — Timing

The device Timing properties allow the driver's response to error conditions to be tailored to fit the application's needs. In many cases, the environment requires changes to these properties for optimum performance. Factors such as electrically generated noise, modem delays, and poor physical connections can influence how many errors or timeouts a communications driver encounters. Timing properties are specific to each configured device.

Property Groups	[-] Communication Timeouts	
General	Connect Timeout (s)	3
Scan Mode	Request Timeout (ms)	5000
Timing	Retry Attempts	3
Auto-Demotion	[-] Timing	
	Inter-Request Delay (ms)	0

Communications Timeouts

Connect Timeout: This property (which is used primarily by Ethernet based drivers) controls the amount of time required to establish a socket connection to a remote device. The device's connection time often takes longer than normal communications requests to that same device. The valid range is 1 to 30 seconds. The default is typically 3 seconds, but can vary depending on the driver's specific nature. If this setting is not supported by the driver, it is disabled.

● **Note:** Due to the nature of UDP connections, the connection timeout setting is not applicable when communicating via UDP.

Request Timeout: This property specifies an interval used by all drivers to determine how long the driver waits for a response from the target device to complete. The valid range is 50 to 9,999,999 milliseconds (167.6667 minutes). The default is usually 1000 milliseconds, but can vary depending on the driver. The default timeout for most serial drivers is based on a baud rate of 9600 baud or better. When using a driver at lower baud rates, increase the timeout to compensate for the increased time required to acquire data.

Attempts Before Timeout: This property specifies how many times the driver issues a communications request before considering the request to have failed and the device to be in error. The valid range is 1 to 10. The default is typically 3, but can vary depending on the driver's specific nature. The number of attempts configured for an application depends largely on the communications environment. This property applies to both connection attempts and request attempts.

Timing

Inter-Request Delay: This property specifies how long the driver waits before sending the next request to the target device. It overrides the normal polling frequency of tags associated with the device, as well as one-time reads and writes. This delay can be useful when dealing with devices with slow turnaround times and in cases where network load is a concern. Configuring a delay for a device affects communications with all other devices on the channel. It is recommended that users separate any device that requires an inter-request delay to a separate channel if possible. Other communications properties (such as communication serialization) can extend this delay. The valid range is 0 to 300,000 milliseconds; however, some drivers may limit the maximum value due to a function of their particular design. The default is 0, which indicates no delay between requests with the target device.

● **Note:** Not all drivers support Inter-Request Delay. This setting does not appear if it is not available.

Device Properties — Auto-Demotion

The Auto-Demotion properties can temporarily place a device off-scan in the event that a device is not responding. By placing a non-responsive device offline for a specific time period, the driver can continue to optimize its communications with other devices on the same channel. After the time period has been reached, the driver re-attempts to communicate with the non-responsive device. If the device is responsive, the device is placed on-scan; otherwise, it restarts its off-scan time period.

Property Groups	<div style="border: 1px solid #ccc; padding: 2px;"> Auto-Demotion </div>	
General	Demote on Failure	Enable ▼
Scan Mode	Timeouts to Demote	3
Timing	Demotion Period (ms)	10000
Auto-Demotion	Discard Requests when Demoted	Disable

Demote on Failure: When enabled, the device is automatically taken off-scan until it is responding again.

● **Tip:** Determine when a device is off-scan by monitoring its demoted state using the `_AutoDemoted` system tag.

Timeouts to Demote: Specify how many successive cycles of request timeouts and retries occur before the device is placed off-scan. The valid range is 1 to 30 successive failures. The default is 3.

Demotion Period: Indicate how long the device should be placed off-scan when the timeouts value is reached. During this period, no read requests are sent to the device and all data associated with the read requests are set to bad quality. When this period expires, the driver places the device on-scan and allows for

another attempt at communications. The valid range is 100 to 3600000 milliseconds. The default is 10000 milliseconds.

Discard Requests when Demoted: Select whether or not write requests should be attempted during the off-scan period. Disable to always send write requests regardless of the demotion period. Enable to discard writes; the server automatically fails any write request received from a client and does not post a message to the Event Log.

Device Properties — Device Settings

Property Groups	[-] Device Settings	
General	Default Float Precision	0
Scan Mode	RS232/485 Echo On	Enable
Timing		
Auto-Demotion		
Device Settings		
Redundancy		

Default Float Precision: Specifies the default Floating point precision to use when writing Float data to Control Parameters. For example, when writing 50.02 from the client, the Float value received by the server could be 50.019999. Setting the parameter to 3 would send the value 50.019 in the write operation. Valid precision values range from 0 (no fractional component) to 5. Default is 0.

● **Note:** For many of the M-Series devices such as the ML-Drive, only two parameters allow for precision, while all other parameters have fixed decimal notation. Set the master precision to 0. The two parameters CP20 and CP21 that allow precision can be set using the dot-precision notation.

RS232/485 Echo On: Enable this setting if the RS232/485 converter's receiver is always on. This setting should be disabled when using an RS-422 converter. Default setting is Enable.

Device Properties — Redundancy

Property Groups	[-] Redundancy	
General	Secondary Path	...
Scan Mode	Operating Mode	Switch On Failure
Timing	Monitor Item	
Redundancy	Monitor Interval (s)	300
	Return to Primary ASAP	Yes

Redundancy is available with the Media-Level Redundancy Plug-In.

● *Consult the website, a sales representative, or the user manual for more information.*

Data Types Description

Data Type	Description
Boolean	Single bit
Word	Unsigned 16 bit value bit 0 is the low bit bit 15 is the high bit
Short	Signed 16 bit value bit 0 is the low bit bit 14 is the high bit bit 15 is the sign bit
DWord	Unsigned 32 bit value bit 0 is the low bit bit 31 is the high bit
Long	Signed 32 bit value bit 0 is the low bit bit 30 is the high bit bit 31 is the sign bit
Float	32 bit Floating point value The driver interprets two consecutive registers as a floating-point value by making the first register the low word and the second register the high word.

Address Descriptions

Address specifications vary depending on the model in use. Select a link from the following list to obtain specific address information for the model of interest.

[M-Cut](#)

[M-Drive](#)

[M-Rotary](#)

[M-Shuttle](#)

[M-Track](#)

[M-Traverse](#)

[M-Trim](#)

[ML-Drive](#)

[ML-Trim](#)

● **Note:** The actual number of available addresses depends on the Contrex M-Series device in use. Refer to the device documentation for address ranges.

M-Cut Addressing

The following addresses are valid. The default data types for dynamically defined tags are shown in **bold**.

Memory	Syntax	Data Type	Access
Monitor Variables	MV00-MV99	Long, DWord, Float	Read Only
Control Parameters	CP00-CP99	Long, DWord, Float*	Read/Write
Control Commands	CC0.Code	Boolean	Write Only

*If a Float address has a bit appended (0 to 5 allowed), this will represent the Floating precision on any writes to the device.

● **Note:** For more information on Floating point precision, refer to [Device Settings](#).

**Valid Code: To execute these commands, write to the address as shown below.

Code	Description
01	Stop
02	Halt
03	Batch Reset
04	Resume Move
05	Move
06	Home Return
07	Back Step
08	Home To Index
09	Home Set
10	Jog Start
11	Jog Stop

Code	Description
12	Forward Select
13	Reverse Select
14	Profile 1 Select
15	Profile 2 Select
16	Profile 3 Select
17	Profile 4 Select

For more information on these command control codes, consult the device documentation.

Examples

1. To send the **Stop** command to the controller, use the syntax CC0.1 and write to the address.
2. To initiate a **Home Return**, use the syntax CC0.6 and write to the address.

M-Drive Addressing

The following addresses are valid. The default data types for dynamically defined tags are shown in **bold**.

Memory	Syntax	Data Type	Access
Monitor Variables	MV00-MV99	Short, Word, Float	Read Only
Control Parameters	CP00-CP99	Short, Word, Float*	Read/Write
Control Commands	CC0.Code	Boolean	Write Only

*If a Float address has a bit appended (0 to 5 allowed), this will represent the Floating precision on any writes to the device.

● **Note:** For more information on Floating point precision, refer to [Device Settings](#).

**Valid Code: To execute these commands, write to the address as shown below.

Code	Description
01	Fast Stop
02	Ramp Stop
03	Run
04	Enable Primary Mode
05	Enable Secondary Mode
08	Enable Closed Loop
09	Enable Open Loop
10	Enable Primary Setpoint 1
11	Enable Primary Setpoint 2
12	Enable Secondary Setpoint 3
13	Enable Secondary Setpoint 4
14	Ramp Disable

Code	Description
15	Ramp Enable

For more information on these command control codes, consult the device documentation.

Examples

1. To send the **Fast Stop** command to the controller, use the syntax CC0.1 and write to the address.
2. To initiate a **Ramp Disable**, use the syntax CC0.14 and write to the address.

M-Rotary Addressing

The following addresses are valid. The default data types for dynamically defined tags are shown in **bold**.

Memory	Syntax	Data Type	Access
Monitor Variables	MV00-MV99	Long, DWord, Float	Read Only
Control Parameters	CP00-CP99	Long, DWord, Float*	Read/Write
Control Commands	CC0.Code	Boolean	Write Only

*If a Float address has a bit appended (0 to 5 allowed), this will represent the Floating precision on any writes to the device.

● **Note:** For more information on Floating point precision, refer to [Device Settings](#).

**Valid Code: To execute these commands, write to the address as shown below.

Code	Description
01	Fast Stop
02	Ramp Stop
03	Run
06	Batch Initiate

For more information on these command control codes, consult the device documentation.

Examples

1. To send the **Fast Stop** command to the controller, use the syntax CC0.1 and write to the address.
2. To initiate a **Batch Initiate**, use the syntax CC0.6 and write to the address.

M-Shuttle Addressing

The following addresses are valid. The default data types for dynamically defined tags are shown in **bold**.

Memory	Syntax	Data Type	Access
Monitor Variables	MV00-MV99	Long, DWord, Float	Read Only
Control Parameters	CP00-CP99	Long, DWord, Float*	Read/Write

Memory	Syntax	Data Type	Access
Control Commands	CC0.Code	Boolean	Write Only

*If a Float address has a bit appended (0 to 5 allowed), this will represent the Floating precision on any writes to the device.

● **Note:** For more information on Floating point precision, refer to [Device Settings](#).

**Valid Code: To execute these commands, write to the address as shown below.

Code	Description
01	Fast Stop
03	Run
04	Home Return
05	Home Seek
06	Home Set
07	Batch Reset
08	Setpoint Select 1
09	Setpoint Select 2
10	Setpoint Select 3
11	Setpoint Select 4

For more information on these command control codes, consult the device documentation.

Examples

1. To send the **Fast Stop** command to the controller, use the syntax CC0.1 and write to the address.
2. To initiate a **Home Return**, use the syntax CC0.4 and write to the address.

M-Track Addressing

The following addresses are valid. The default data types for dynamically defined tags are shown in **bold**.

Memory	Syntax	Data Type	Access
Monitor Variables	MV00-MV99	Long, DWord, Float	Read Only
Control Parameters	CP00-CP99	Long, DWord, Float*	Read/Write
Control Commands	CC0.Code	Boolean	Write Only

*If a Float address has a bit appended (0 to 5 allowed), this will represent the Floating precision on any writes to the device.

● **Note:** For more information on Floating point precision, refer to [Device Settings](#).

**Valid Code: To execute these commands, write to the address as shown below.

Code	Description
01	Fast Stop
02	Ramp Stop
03	Run
04	Enable Master Mode
05	Enable Follower Mode
06	Batch Initiate

For more information on these command control codes, consult the device documentation.

Examples

1. To send the **Fast Stop** command to the controller, use the syntax CC0.1 and write to the address.
2. To initiate a **Batch Initiate**, use the syntax CC0.6 and write to the address.

M-Traversal Addressing

The following addresses are valid. The default data types for dynamically defined tags are shown in **bold**.

Memory	Syntax	Data Type	Access
Monitor Variables	MV00-MV99	Long, DWord, Float	Read Only
Control Parameters	CP00-CP99	Long, DWord, Float*	Read/Write
Control Commands	CC0.Code	Boolean	Write Only

*If a Float address has a bit appended (0 to 5 allowed), this will represent the Floating precision on any writes to the device.

● **Note:** For more information on Floating point precision, refer to [Device Settings](#).

**Valid Code: To execute these commands, write to the address as shown below.

Code	Description
01	Fast Stop
03	Run
04	Home Return
05	Home Seek
06	Home Set
07	Batch Reset
08	Setpoint Select 1
09	Setpoint Select 2
10	Setpoint Select 3
11	Setpoint Select 4

For more information on these command control codes, consult the device documentation.

Examples

1. To send the **Fast Stop** command to the controller, use the syntax CC0.1 and write to the address.
2. To initiate a **Home Return**, use the syntax CC0.4 and write to the address.

M-Trim Addressing

The following addresses are valid. The default data types for dynamically defined tags are shown in **bold**.

Memory	Syntax	Data Type	Access
Monitor Variables	MV00-MV99	Short, Word, Float	Read Only
Control Parameters	CP00-CP99	Short, Word, Float*	Read/Write
Control Commands	CC0.Code	Boolean	Write Only

*If a Float address has a bit appended (0 to 5 allowed), this will represent the Floating precision on any writes to the device.

● **Note:** For more information on Floating point precision, refer to [Device Settings](#).

**Valid Code: To execute these commands, write to the address as shown below.

Code	Description
01	Fast Stop
02	Ramp Stop
03	Run
04	Enable Primary Mode
05	Enable Secondary Mode
06	Forward
07	Reverse
08	Enable Closed Loop
09	Enable Open Loop
10	Enable Primary Setpoint 1
11	Enable Primary Setpoint 2
12	Enable Secondary Setpoint 3
13	Enable Secondary Setpoint 4
14	Ramp Disable
15	Ramp Enable

For more information on these command control codes, consult the device documentation.

Examples

1. To send the **Fast Stop** command to the controller, use the syntax CC0.1 and write to the address.
2. To initiate a **Ramp Disable**, use the syntax CC0.14 and write to the address.

ML-Drive Addressing

The following addresses are valid. The default data types for dynamically defined tags are shown in **bold**.

Memory	Syntax	Data Type	Access
Monitor Variables	MV00-MV99	Short, Word, Float	Read Only
Control Parameters	CP00-CP99	Short, Word, Float*	Read/Write
Control Commands	CC0.Code	Boolean	Write Only

*If a Float address has a bit appended (0 to 5 allowed), this will represent the Floating precision on any writes to the device.

● **Note:** For more information on Floating point precision, refer to [Device Settings](#).

**Valid Code: To execute these commands, write to the address as shown below.

Code	Description
01	Fast Stop
02	Ramp Stop
03	Run
04	Enable Master Mode
05	Enable Follower Mode
10	Enable Setpoint 1
11	Enable Setpoint 2
12	Enable Setpoint 3
13	Enable Setpoint 4

For more information on these command control codes, consult the device documentation.

Examples

1. To send the **Fast Stop** command to the controller, use the syntax CC0.1 and write to the address.
2. To initiate a **Ramp Stop**, use the syntax CC0.2 and write to the address.

ML-Trim Addressing

The following addresses are valid. The default data types for dynamically defined tags are shown in **bold**.

Memory	Syntax	Data Type	Access
Monitor Variables	MV00-MV99	Short, Word, Float	Read Only
Control Parameters	CP00-CP99	Short, Word, Float*	Read/Write
Control Commands	CC0.Code	Boolean	Write Only

*If a Float address has a bit appended (0 to 5 allowed), this will represent the Floating precision on any writes to the device.

● **Note:** For more information on Floating point precision, refer to [Device Settings](#).

**Valid Code: To execute these commands, write to the address as shown below.

Code	Description
01	Fast Stop
02	Ramp Stop
03	Run
04	Enable Master Mode
05	Enable Follower Mode
10	Enable Setpoint 1
11	Enable Setpoint 2
12	Enable Setpoint 3
13	Enable Setpoint 4

For more information on these command control codes, consult the device documentation.

Examples

1. To send the **Fast Stop** command to the controller, use the syntax CC0.1 and write to the address.
2. To initiate a **Ramp Stop**, use the syntax CC0.2 and write to the address.

Error Descriptions

The following error/warning messages may be generated. Click on the link for a description of the message.

Address Validation

[Missing address](#)

[Device address '<address>' contains a syntax error](#)

[Address '<address>' is out of range for the specified device or register](#)

[Device address '<address>' is not supported by model '<model name>'](#)

[Data Type '<type>' is not valid for device address '<address>'](#)

[Device address '<address>' is Read Only](#)

Serial Communications

[COMn does not exist](#)

[Error opening COMn](#)

[COMn is in use by another application](#)

[Unable to set comm parameters on COMn](#)

[Communications error on '<channel name>' \[<error mask>\]](#)

Device Status Messages

[Device '<device name>' is not responding](#)

Device Specific Messages

[Unable to write to '<address>' on device '<device name>.' Contrex Error \(<error code>\) <error description>](#)

[Deactivating Tag '<address>' on device '<device name>.' Contrex Error \(<error code>\) <error description>](#)

Missing address

Error Type:

Warning

Possible Cause:

A tag address that has been specified dynamically has no length.

Solution:

Re-enter the address in the client application.

Device address '<address>' contains a syntax error

Error Type:

Warning

Possible Cause:

A tag address that has been specified dynamically contains one or more invalid characters.

Solution:

Re-enter the address in the client application.

Address '<address>' is out of range for the specified device or register

Error Type:

Warning

Possible Cause:

A tag address that has been specified dynamically references a location that is beyond the range of supported locations for the device.

Solution:

Verify the address is correct; if it is not, re-enter it in the client application.

Device address '<address>' is not supported by model '<model name>'

Error Type:

Warning

Possible Cause:

A tag address that has been specified dynamically references a location that is valid for the communications protocol but not supported by the target device.

Solution:

Verify the address is correct; if it is not, re-enter it in the client application. Also verify that the selected model name for the device is correct.

Data Type '<type>' is not valid for device address '<address>'

Error Type:

Warning

Possible Cause:

A tag address that has been specified dynamically has been assigned an invalid data type.

Solution:

Modify the requested data type in the client application.

Device address '<address>' is Read Only

Error Type:

Warning

Possible Cause:

A tag address that has been specified dynamically has a requested access mode that is not compatible with what the device supports for that address.

Solution:

Change the access mode in the client application.

COMn does not exist

Error Type:

Fatal

Possible Cause:

The specified COM port is not present on the target computer.

Solution:

Verify that the proper COM port has been selected.

Error opening COMn

Error Type:

Fatal

Possible Cause:

The specified COM port could not be opened due to an internal hardware or software problem on the target computer.

Solution:

Verify that the COM port is functional and may be accessed by other Windows applications.

COMn is in use by another application

Error Type:

Fatal

Possible Cause:

The serial port assigned to a device is being used by another application.

Solution:

Verify that the correct port has been assigned to the channel. Also verify that only one copy of the current project is running.

Unable to set comm parameters on COMn

Error Type:

Fatal

Possible Cause:

The serial parameters for the specified COM port are not valid.

Solution:

Verify the serial parameters and make any necessary changes.

Communications error on '<channel name>' [<error mask>]

Error Type:

Serious

Error Mask Definitions:

B= Hardware break detected.
F= Framing error.
E= I/O error.
O= Character buffer overrun.
R= RX buffer overrun.
P= Received byte parity error.
T= TX buffer full.

Possible Cause:

1. The serial connection between the device and the host PC is bad.
2. The communications parameters for the serial connection are incorrect.

Solution:

1. Verify the cabling between the PC and the device.
2. Verify that the specified communications parameters match those of the device.

Device '<device name>' is not responding

Error Type:

Serious

Possible Cause:

1. The serial connection between the device and the host PC is broken.
2. The communications parameters for the serial connection are incorrect.
3. The named device may have been assigned an incorrect Network ID.
4. The response from the device took longer to receive than the amount of time specified in the "Request Timeout" device setting.

Solution:

1. Verify the cabling between the PC and the device.
2. Verify that the specified communications parameters match those of the device.
3. Verify that the Network ID given to the named device matches that of the actual device.
4. Increase the Request Timeout setting so that the entire response can be handled.

Unable to write to '<address>' on device '<device name>'. Contrex Error (<error code>) <error description>

Error Type:

Serious

Possible Cause:

1. The serial connection between the device and the host PC is broken.
2. The communications parameters for the serial connection are incorrect.
3. The named device may have been assigned an incorrect Network ID.
4. The address that is being written to is invalid or the data is out of range.

Solution:

1. Verify the cabling between the PC and the device.
2. Verify the specified communications parameters match those of the device.
3. Verify that the Network ID given to the named device matches that of the actual device.
4. Verify that the address is valid in the controller. Use the Contrex Error Description to determine the cause of the error.

See Also:

[Error Descriptions](#)

Deactivating Tag '<address>' on device '<device name>.' Contrex Error (<error code>) <error description>

Error Type:

Serious

Possible Cause:

An attempt has been made to reference a nonexistent location in the specified device. The driver will deactivate the tag.

Solution:

Verify the tags assigned to addresses in the specified range on the device and eliminate ones that reference invalid locations. Use the Contrex Error Description that was returned to the driver to determine the cause of the error.

See Also:

[Error Descriptions](#)

Resources

In addition to this user manual, there are a variety of resources available to assist customers, answer questions, provide more detail about specific implementations, or help with troubleshooting specific issues.

[Knowledge Base](#)

[Whitepapers](#)

[Connectivity Guides](#)

[Technical Notes](#)

[Training Programs](#)

[Training Videos](#)

[Kepware Technical Support](#)

[PTC Technical Support](#)

Index

A

Address '<address>' is out of range for the specified device or register 26

Address Descriptions 17

Advanced Channel Properties 10

Attempts Before Timeout 14

Auto Dial 9

B

Baud Rate 7

Boolean 16

C

Channel Assignment 11

Channel Properties - General 6

Channel Properties — Write Optimizations 9

Close Idle Connection 8-9

COM ID 7

Communications error on '<channel name>' [<error mask>] 27

Communications Timeouts 13-14

COMn does not exist 27

COMn is in use by another application 27

Connect Timeout 13

Connection Type 7

D

Data Bits 7

Data Collection 12

Data Type '<type>' is not valid for device address '<address>' 26

Data Types Description 16

Deactivating Tag '<address>' on device '<device name>'. Contrex Error (<error code>) <error description> 29

Demote on Failure 14

Demotion Period 14
Description 11
Device '<device name>' is not responding 28
Device address '<address>' contains a syntax error 25
Device address '<address>' is not supported by model '<model name>' 26
Device address '<address>' is Read Only 26
Device ID 5
Device Properties — Auto-Demotion 14
Device Properties — Device Settings 15
Device Properties — General 11
Diagnostics 6
Discard Requests when Demoted 15
Do Not Scan, Demand Poll Only 13
Driver 6, 11
Duty Cycle 10
DWord 16

E

Error Descriptions 25
Error opening COMn 27

F

Float 16
Flow Control 8
Framing 28

I

ID 12
Idle Time to Close 8-9
IEEE-754 floating point 10
Initial Updates from Cache 13
Inter-Request Delay 14

L

Long 16

M

M-Cut Addressing 17

M-Drive Addressing 18

M-Rotary Addressing 19

M-Shuttle Addressing 19

M-Track Addressing 20

M-Traverse Addressing 21

M-Trim Addressing 22

Mask 27

Missing address 25

ML-Drive Addressing 23

ML-Trim Addressing 23

Model 11

Modem 9

N

Name 11

Network 5

Network Adapter 9

Non-Normalized Float Handling 10

O

Operational Behavior 8

Optimization Method 9

Overrun 28

Overview 4

P

Parity 7, 28

Physical Medium 7

R

Read Processing 9

Redundancy 15

Report Comm. Errors 8-9

Request All Data at Scan Rate 13

Request Data No Faster than Scan Rate 13

Request Timeout 14

Resources 30

Respect Client-Specified Scan Rate 13

Respect Tag-Specified Scan Rate 13

S

Scan Mode 13

Serial Communications 7

Serial Port Settings 7

Setup 5

Simulated 12

Stop Bits 8

T

Timeouts to Demote 14

U

Unable to set comm parameters on COMn 27

Unable to write to '<address>' on device '<device name>.' Contrex Error (<error code>) <error description> 28

W

Write All Values for All Tags 9

Write Only Latest Value for All Tags 10

Write Only Latest Value for Non-Boolean Tags 10

Write Optimizations 9